

226R

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A 226R
GEAR




Position	Article	Quantity	Notes	Kit
1	537 33 32-02	1		1
2	503 20 15-02	1		1
3	510 90 89-01	1	Screw M5x12	
4	503 20 07-25	1	Screw M5x25	
5	738 21 99-00	1		1
6	738 21 99-02	1		1
7	735 31 11-00	1		1
8	735 31 25-10	1		1
9	738 21 98-00	1		1
11	537 18 95-01	1	Screw M6x20	
12	503 93 55-01	1		
13	738 21 01-04	1		1
14	735 31 28-10	1		1
15	537 23 49-01	1		
16	537 29 26-01	1		15
17	537 28 56-01	1		
18	503 85 63-01	1		

B 226R
TUBE & SHAFT





Position	Article	Quantity	Notes	Kit
1	528 84 19-01	1		
2	528 84 20-01	1		
3	521 82 21-01	1		
4	510 96 31-01	1		
5	521 53 87-01	1		
6	510 48 23-01	1		

C 226R
HANDLEBAR



Position	Article	Quantity	Notes	Kit
1	528 81 74-01	1		
2	528 81 75-01	1		
3	514 39 53-01	1		
3	576 46 06-01	1	South America only	
4	510 52 32-01	4		3
4	725 53 33-55	4	South America only	3
5	505 29 49-01	1		3
6	514 39 55-01	1		3
7	514 39 56-01	1		3
8	526 73 45-01	2		3
9	537 17 28-02	1		
10	537 17 29-01	1		
11	510 90 94-01	1		
11	503 20 07-45	1	South America only	
12	575 96 06-01	1		
12	731 23 14-01	1	South America only	


D 226R
THROTTLE HANDLE



THROTTLE HANDLE


Position	Article	Quantity	Notes	Kit
1	522 03 66-01	1		
2	537 18 35-07	1		
3	537 16 03-01	1		2
4	537 16 02-03	1		2
5	506 49 77-01	1		2
6	537 16 07-03	1		2
7	503 71 82-01	1		2
8	537 17 42-01	1		2
9	537 17 43-01	1		2
10	503 22 10-13	1		2
11	503 21 66-74	2		2
12	503 20 07-82	1		2

E 226R
CLUTCH





Position	Article	Quantity	Notes	Kit
1	521 77 12-01	1		
2	516 12 41-01	1		1
3	525 95 32-01	1		1
4	506 60 99-01	1		1
5	521 60 98-01	1		1
6	512 36 05-01	1		
7	521 76 83-01	1		
8	521 76 82-01	1		
9	526 73 45-01	2		
10	526 73 44-01	1		
11	513 18 96-01	2		
12	521 75 82-01	2		
13	506 62 94-01	1		
14	506 68 58-01	1		13
15	505 05 44-01	2		
16	511 32 36-01	1		
17	514 23 48-01	2		
18	521 75 88-01	1		
19	510 48 23-01	2		

F 226R
IGNITION



Position	Article	Quantity	Notes	Kit
1	521 76 93-01	1		
2	512 36 16-01	1		
3	515 41 52-01	1		2
4	505 29 88-01	1		2
5	512 36 17-01	1		2
6	505 04 28-01	1		2
7	515 41 53-01	1		2
8	514 18 68-01	2		
9	521 76 97-01	2		
10	504 11 80-01	1		
11	512 36 19-01	1		



G 226R
CYLINDER COVER



CYLINDER COVER

Position	Article	Quantity	Notes	Kit
1	527 91 78-01	1		
2	527 91 87-01	1		
3	505 29 98-01	1		
4	512 36 10-01	1		



H 226R
MUFFLER



MUFFLER


Position	Article	Quantity	Notes	Kit
1	515 41 21-01	1		
2	510 48 16-01	1		
3	516 07 14-01	2		
4	512 35 97-01	1		
5	512 33 29-01	1		

J 226R
STARTER




Position	Article	Quantity	Notes	Kit
1	527 91 81-01	1		
2	506 61 30-01	1		1
3	513 41 68-01	1		1
4	521 75 94-01	1		1
5	504 11 50-01	1		1
6	521 75 96-01	1		1
7	521 75 99-01	1		1
8	521 75 98-01	1		1
9	521 75 97-01	1		1
10	512 36 10-01	4		
11	527 91 88-01	1		
12	513 41 73-01	1		
13	513 41 77-01	1		12
14	513 41 78-01	1		12

K 226R
TANK




Position	Article	Quantity	Notes	Kit
1	521 77 20-01	1		
2	515 45 29-01	1		1
3	506 74 68-01	1		1, 2
4	515 44 78-01	1		1, 2
5	515 41 83-01	1		1, 2
6	506 74 58-01	1		1, 2
7	515 41 85-01	1		1
8	506 70 70-01	1		1
9	515 41 84-01	1		1
10	506 74 15-01	1		
11	515 41 87-01	2		
12	515 49 25-01	1		

L 226R
INTAKE




Position	Article	Quantity	Notes	Kit
1	527 91 85-01	1		
2	523 07 13-01	1		1
3	510 48 31-01	2		
4	515 41 73-01	1		
5	512 36 27-01	1		
6	512 36 29-01	1		5
7	506 61 40-01	1		5
8	512 36 28-01	1		5
9	513 45 49-01	2		5
10	512 38 22-01	1		
11	521 77 48-01	1		
12	506 74 42-01	1		
13	527 91 83-01	1		
14	515 40 99-01	1		
15	510 48 23-01	2		
16	512 35 96-01	1		
17	515 40 90-01	1		

M 226R
CYLINDER & PISTON



Position	Article	Quantity	Notes	Kit
1	525 95 70-01	1		
2	515 40 88-01	1		
3	513 41 25-01	2		
4	515 49 74-01	1	Plug (BPMR7A)	
5	529 25 10-01	2		
6	505 04 52-01	2		
7	505 04 07-01	1		
8	515 49 18-01	1		
9	505 04 10-01	2		
10	505 04 09-01	1		

N 226R
CRANKSHAFT




Page N 226R

CRANKSHAFT


Position	Article	Quantity	Notes	Kit
1	526 52 91-01	1		
2	523 07 17-01	2		
3	506 68 94-01	1		

P 226R
CRANKCASE




Position	Article	Quantity	Notes	Kit
1	515 49 00-01	1		
2	513 48 87-01	1		
3	506 61 29-01	1		
4	506 60 99-01	1		
5	515 41 24-01	1		
6	505 29 61-01	3		1
7	506 60 94-01	4		
8	515 41 26-01	1		
9	505 29 98-01	1		

Q 226R
CARBURETTOR



Position	Article	Quantity	Notes	Kit
1	527 91 83-01	1		
2	513 41 08-01	1		
3	520 95 70-01	1		2
4	521 08 54-01	1		2
5	513 41 07-01	1		2
6	520 97 74-01	1		2
7	505 30 61-01	1		2
8	520 97 72-01	1		2
9	506 74 09-01	1		
10	506 74 10-01	1		
11	505 30 67-01	1		
12	505 30 68-01	1		
13	506 74 08-01	1		
14	506 68 98-01	1		
15	506 74 51-01	1		
17	506 73 86-01	1		
18	506 74 12-01	1		
19	505 30 79-01	2		
20	506 74 60-01	1		
23	512 37 34-01	1		
24	513 30 15-01	1		
25	513 43 78-01	1		
26	513 43 77-01	1		
27	506 74 61-01	1		
28	506 74 11-01	4		
29	521 77 01-01	1		
30	505 30 84-01	1		








R 226R
ACCESSORIES



ACCESSORIES

Position	Article	Quantity	Notes	Kit
1	503 93 42-02	1		
2	503 21 07-16	1		1
3	503 79 88-01	1		1

S 226R
ACCESSORIES



Position	Article	Quantity	Notes	Kit
1	521 81 75-01	1		
1	576 46 07-01	1	South America only	
2	514 09 91-01	1		1
3	505 31 19-01	1		1
4	505 31 20-01	1		1
6	537 31 29-01	1		
7	503 89 01-01	1		
8	531 00 92-48	1		
9	503 97 64-01	1		
10	501 19 22-01	1		
11	503 73 40-01	1		14
12	503 73 41-02	1		14
13	502 02 28-02	1		14
14	537 21 63-01	1		